LITTLE DAVID

OWNERS MANUAL



LEGEND

2" AND 3" CARTRIDGES

THE LOVESHAW CORPORATION 2206 EASTON TURNPIKE, BOX 83 SOUTH CANAAN, PA 18459

TEL: (570) 937-4921 FAX: (570) 937-4370 LOVESHAW - EUROPE UNIT 9, BRUNEL GATE W. PORTWAY INDUSTRIAL ESTATE ANDOVER, HAMPSHIRE SP103SL ENGLAND 44-264-3575-11

P/N: PMLDU/2-3

REV. 10/15/2008 M.C.R. #08-008

TABLE OF CONTENTS
GENERAL SAFETY PRECAUTIONS
ARRIVAL INSPECTIONS
MACHINE SPECIFICATIONS
INTRODUCTION
INSTALLATION
INSTALLATION AND ADJUSTMENT OF DRIVE COMPONENTS
ADJUSTMENT OF LEG EXTENSIONS
OPERATION
MAIN FRAME
HEAD
ELECTRICAL SYSTEM
LUBRICATION
TROUBLE SHOOTING
TAPE CARTRIDGE
TAPE CARTRIDGE MANUAL
ILLUSTRATED ASSEMBLY TABLE OF CONTENTS
ELECTRICAL
WARRANTY

GENERAL SAFETY PRECAUTIONS

BEFORE INSTALLING, OPERATING OR SERVICING THIS EQUIPMENT READ THE FOLLOWING PRECAUTIONS CAREFULLY:

- * THIS MACHINE IS EQUIPPED WITH MOVING BELTS. DO NOT PLACE HANDS NEAR THE REAR OF THIS MACHINE WHEN BELTS ARE MOVING, AS FINGERS MAY BE PINCHED WHERE BELTS ENTER FRAME. ALWAYS USE A ROLLER TYPE EXIT CONVEYOR AND <u>ALWAYS</u> REMOVE BOXES AFTER THEY CLEAR THE EXIT END OF THE MACHINE.
- * FINGER GUARDS ARE PROVIDED TO PREVENT A PINCH-POINT. THEY SHOULD ALWAYS BE IN PLACE WHEN RUNNING THE MACHINE.
- * OBSERVE CAUTION WHEN NEAR CARTRIDGE KNIFE OR WHEN THREADING TAPE. KNIFE IS VERY SHARP, AUTOMATICALLY OPERATED AND IS LINKED TO THE WIPE DOWN ROLLERS.
- * DO NOT ATTEMPT TO OPEN OR WORK ON ELECTRICAL BOX, JUNCTION BOXES, OR OTHER ELECTRICAL COMPONENTS WITHOUT FIRST DISCONNECTING POWER TO THE MACHINE. SHOCK HAZARD EXISTS IF POWER IS NOT DISCONNECTED.
- * DO NOT BYPASS ANY DESIGNED-IN SAFETY FEATURES SUCH AS INTERLOCKS, GUARDS, OR SHIELDS.
- * DO NOT PLACE HANDS OR BODY INSIDE CONFINES OF UNIFORM TYPE MACHINES UNLESS HEAD IS SECURELY LOCKED AND POWER IS DISCONNECTED.
- * ALWAYS DISCONNECT POWER SOURCE BEFORE SERVICING MACHINE.
- * WHEN OPERATING A SEMI-AUTOMATIC MACHINE, HOLD BOX FLAPS DOWN AT THE EDGE OF THE BOX. RELEASE HANDS AS SOON AS THE BELTS TAKE THE BOX.
- * DO NOT WEAR JEWELRY, LOOSE CLOTHING, SUCH AS TIES, SCARVES, ETC., AND LONG HAIR SHOULD BE PULLED BACK WHEN OPERATING THE MACHINE.

ARRIVAL INSPECTION

* * * * N O T E * * * *

WHEN UNCRATING MACHINE, CHECK FOR ANY PHYSICAL DAMAGE.

IF ANY DAMAGE HAS OCCURRED, NOTIFY COMPANY IMMEDIATELY.

MACHINE SPECIFICATIONS

MACHINE DIMENSIONS:

HEIGHT: WIDTH: LENGTH: (without (with rail		1554mm 783mm 1016mm 1324mm
TABLE HEIGHT (adju	ustable):	
MINIMUM: MAXIMUM:	22 ¼ inches 32 ¼ inches	565 mm 819 mm
ELECTRICAL:		
STANDARD:	115V/1/60	
OPTIONAL:	220V/1/50,60 220V/3/50,60 240V/1/50 380V/3/50 440V/3/50 440V/3/60	
BOX CAPACITY:		
LENGTH:	4.5 inches to unlimited max.	114 mm to unlimited max.
WIDTH:	4.5 inches to 20 inches	114 mm to 559 mm
HEIGHT:	2 inches to 24 inches	51 mm to 609 mm
OPERATING SPEED		
BELT SPEED: NUMBER OF BOXES	80 ft./min. S/MIN. VARIES WI	18m/min. TH BOX SIZE
CLOSURE MATERIA	L - PRESSURE SENSITIVE TAPE	
WIDTH:	1.5 inches 2 inches	38 mm to 50 mm
MAX. ROLL DIAMET		380 mm
WEIGHT: (uncrated)	203 LBS.	104 KG.

INTRODUCTION

THE **LITTLE DAVID LDU UNIFORM PRESSURE SENSITIVE TAPER** IS DESIGNED TO TAPE THE TOP AND BOTTOM FLAPS OF A WIDE VARIETY OF BOX SIZES. AFTER MANUALLY ADJUSTING THE MACHINE FOR THE BOX SIZE, THE OPERATOR ONLY HAS TO FOLD THE FLAPS AND PUSH THE BOX INTO THE MACHINE AFTER WHICH THE MACHINE WILL TAPE THE TOP AND BOTTOM FLAPS AND DISCHARGE THE BOX.

THE SIMPLE BUT SOPHISTICATED DESIGN INSURES A MINIMUM OF MAINTENANCE PROBLEMS, AND THE MACHINE CAN BE EASILY OPERATED BY UNSKILLED OPERATORS. DUE TO ITS SMALL SIZE AND SIMPLE PLUG-IN CONNECTION, IT CAN BE QUICKLY MOVED TO THE AREA WHERE IT IS NEEDED. IT MAY STAND ALONE OR IF DESIRED, BE INCORPORATED IN A CONVEYOR SYSTEM.

THE FINEST MATERIALS AND WORKMANSHIP HAVE BEEN EMPLOYED TO INSURE SATISFACTION. IF ADJUSTMENTS OR REPAIRS BECOME NECESSARY YOU WILL FIND SIMPLE INSTRUCTIONS OUTLINED IN THIS MANUAL. IF A PROBLEM OCCURS WHICH IS NOT COVERED IN THE MANUAL, PLEASE TELEPHONE OUR SERVICE DEPARTMENT AT:

> LOVESHAW CORPORATION 2206 EASTON TURNPIKE SOUTH CANAAN, PA 18459 PHONE: 1-800-962-2633 / 570-937-4921 FAX: 570-937-4370

LOVESHAW - EUROPE UNIT 9, BRUNEL GATE WEST PORTWAY INDUSTRIAL ESTATE ANDOVER, HAMPSHIRE SP10 3SL ENGLAND

OR YOUR NEAREST LITTLE DAVID DISTRIBUTOR

INSTALLATION

FOR DOMESTIC CUSTOMERS ONLY - THE LITTLE DAVID IS SHIPPED COMPLETELY ASSEMBLED.

THE LITTLE DAVID IS READY FOR OPERATION AFTER PLUGGING IT INTO AN APPROPRIATE GROUNDED ELECTRICAL OUTLET. THE CONNECTION CABLE IS LOCATED ON THE OPERATOR SIDE OF THE MACHINE.

THE HEIGHT OF THE MACHINE CAN BE ADJUSTED FROM 22 ¼ " TO 33 ¼" (565 mm to 844 mm) IN ANY INCREMENT BY ADJUSTING THE HEIGHT OF THE LEG EXTENSIONS.

THE MACHINE SHOULD BE PLACED ON A FLAT LEVEL FLOOR SO THAT IT DOES NOT ROCK. DUE TO ITS PORTABILITY AND EASY PLUG-IN CONNECTION, THE MACHINE MAY BE QUICKLY MOVED TO VARIOUS LOCATIONS AS THE NEED ARISES. OPTIONAL CASTERS ARE AVAILABLE, IF REQUIRED. THERE ARE HOLES PROVIDED IN THE LEG EXTENSIONS FOR LEVELING BOLTS, IF REQUIRED.

AN OPTIONAL INFEED TABLE CAN BE INSTALLED AT THE INFEED END OF THE MACHINE, HOWEVER, A CONVEYOR MAY BE USED INSTEAD. THE INFEED TABLE CAN BE USED SO THAT THE PACKER CAN FILL THE BOXES AND CLOSE THE FLAPS PRIOR TO FEEDING THE BOXES INTO THE MACHINE. A CONVEYOR SHOULD BE PROVIDED AT THE OUTFEED END OF THE MACHINE TO RECEIVE THE BOXES AS THEY ARE DISCHARGED FROM THE MACHINE. IMPORTANT: BE SURE THE TABLE AND CONVEYOR ARE ¼" (6 mm) BELOW THE MACHINE BELT HEIGHT.

INSTALLATION AND ADJUSTMENT OF DRIVE COMPONENTS

THE MACHINE CONVEYOR SYSTEM CONSISTS OF (4) KEY COMPONENTS.

- 1. MOTOR / GEARBOX SYSTEM
- 2. DRIVE ROLLERS
- 3. BELTS
- 4. FRONT BELT TENSIONER AND GUIDES

MOTOR / GEARBOX SYSTEM:

THE MOTOR AND GEARBOX SYSTEM IS LOCATED IN THE REAR OF THE MACHINE TUCKED UNDER THE FRAME. SEE ASSEMBLY FOR INDIVIDUAL PART NUMBERS. THE SYSTEM CAN BE REMOVED FOR INSPECTION AND REPLACEMENTS BY FOLLOWING THIS PROCEDURE.

- 1. DISCONNECT POWER FROM MACHINE AND LOCK OUT POWER USING LOCKOUT BRACKET ON STARTER SWITCH.
- 2. LOOSEN THE (4) MOUNTING BOLTS AT THE GEARBOX SLIDE BRACKET. THEN SLIDE THE MOTOR AND GEARBOX ASSEMBLY UP TOWARDS THE FRAME. THIS WILL REMOVE THE TENSION FROM THE DRIVE CHAIN AND ALLOW THE DRIVE CHAIN TO BE REMOVED FROM THE ASSEMBLY.
- 3. THE POWER SUPPLY CORD MUST BE REMOVED FROM MOTOR FOR REMOVAL FROM MACHINE.
- 4. THEN REMOVE THE (4) MOUNTING BOLTS WHILE SUPPORTING THE MOTOR AND GEARBOX ASSEMBLY THEM REMOVE FROM THE MACHINE.
- 5. THE MOTOR MAY BE REMOVED FROM GEARBOX ASSEMBLY BY REMOVING THE (4) MOUNTING BOLTS ON THE GEARBOX FLANGE.
- 6. THE PROCESS SHOULD BE REVERSED TO REASSEMBLE THE SYSTEM.

DRIVE ROLLERS ADJUSTMENT AND BELT REPLACEMENT:

THE DRIVE ROLLERS ARE LOCATED ON THE DRIVE SHAFT AT THE REAR OF THE MACHINE. THEY TRANSFER POWER FROM THE GEARBOX ASSEMBLY TO THE BELTS. THE ADJUSTMENT FOR THE DRIVE ROLLERS IS AS FOLLOWS. EACH BELT IS REPLACED SEPARATELY; HOWEVER, IT IS RECOMMENDED THAT BOTH BELTS BE REPLACED AT THE SAME TIME. IT IS IMPORTANT THAT FACTORY SUPPLIED BELTS BE USED SINCE THEY ARE OF SPECIAL CONSTRUCTION. TO REPLACE BELTS FOLLOW INSTRUCTIONS #1 AND #2 LISTED BELOW.

- 1. TURN ON MACHINE UNTIL THE LACED PORTION OF THE BELT IS SHOWING THEN STOP THE MACHINE. (USE EXTREME CAUTION WHEN WORKING ON THE MACHINE WHILE POWER IS CONNECTED.) PULL UPWARD ON THE BELT TO COLLAPSE THE SELF-TENSIONING ASSEMBLY AT THE FRONT END OF THE MACHINE. PLACE A WEDGE (EXAMPLE: SCREWDRIVER HANDLE) BETWEEN THE FRAME AND BELT TO KEEP THE SELF-TENSIONING ASSEMBLY COLLAPSED. THIS WILL ALLOW THE REMOVAL OF THE PIN IN THE LACED PORTION OF THE BELT.
- 2. SLIDE THE BELT OUT OF THE MACHINE AND REPEAT FOR THE OTHER BELT.
- 3. THE PROCESS SHOULD BE REVERSED TO REASSEMBLE THE SYSTEM.

FRONT BELT TENSIONER ASSEMBLIES AND GUIDE ADJUSTMENT:

THE FRONT BELT TENSIONER ASSEMBLIES ARE LOCATED AT THE FRONT END OF THE MACHINE TUCKED INSIDE THE FRAME. THIS IS A SELF-TENSIONING SYSTEM THAT CONSTANTLY PLACES FORCE ON THE BELT TO TAKE UP ANY ADJUSTMENT IN LENGTH. THEY CONSIST OF (3) ITEMS - A TENSION ROLLER BRACKET WITH ROLLER, (2) GUIDE ROLLERS, AND (2) COMPRESSION SPRINGS. EACH TENSIONER CAN BE MOVED INDEPENDENTLY IN ORDER TO ACCOMMODATE THE 2" OR 3" TAPE CARTRIDGES. SEE ASSEMBLY FOR INDIVIDUAL PART NUMBERS. THE ADJUSTMENT OF THE FRONT BELT TENSIONER IS AS FOLLOWS.

- 1. DISCONNECT POWER FROM MACHINE AND LOCK OUT POWER USING LOCKOUT BRACKET ON STARTER SWITCH.
- 2. REFER TO ASSEMBLY FOR DIMENSIONS TO LOCATE THE POSITION OF THE TENSIONER.
- 3. THERE ARE SPLIT SHAFT COLLARS LOCATED ON EACH SIDE OF THE TENSIONER ASSEMBLY. LOOSEN THE COLLARS AND SLIDE TENSIONER INTO POSITION.
- 4. TIGHTEN COLLARS AFTER IN POSITION AND RESTORE POWER TO MACHINE.

ADJUSTMENT OF LEG EXTENSIONS

LEG EXTENSION ADJUSTMENT

THE LEG EXTENSIONS ARE LOCATED ON THE INSIDE OF THE (4) LEGS OF THE MACHINE. THEY HAVE THE ABILITY TO BE ADJUSTED INFINITELY IN THEIR RANGE. SEE ASSEMBLY FOR INDIVIDUAL PART NUMBERS. THE PROCEDURE FOR ADJUSTING IS AS FOLLOWS.

- 1. DISCONNECT POWER FROM MACHINE AND LOCK OUT POWER USING LOCKOUT BRACKET ON STARTER SWITCH.
- 2. REMOVE WEIGHT OFF MACHINE LEG.
- 3. LOOSEN THE 12 mm LOCKING BOLT LOCATED ON THE INSIDE OF THE MACHINE LEG. THIS WILL ALLOW THE LEG EXTENSION TO SLIDE FREELY TO PROPER HEIGHT.
- 4. TIGHTEN THE LOCKING BOLT SECURELY ENOUGH TO ENSURE PROPER CLAMPING.
- 5. REPEAT PROCESS ON ALL LEGS UNTIL THE DESIRED MACHINE HEIGHT IS OBTAINED.

OPERATION

AFTER THE TAPE CARTRIDGES ARE LOADED, THE MACHINE IS READY TO SEAL BOXES. PLACE A SAMPLE BOX OF THE SIZE TO BE SEALED ON THE INFEED TABLE, FOLD THE FLAPS AND PUT JUST IN FRONT OF THE TOP TAPE CARTRIDGE. RELEASE THE SIDE RAILS BY TURNING THE SIDE RAIL LOCK HAND WHEEL COUNTERCLOCKWISE AND MOVE SIDE RAILS IN UNTIL BOTH RAILS ARE IN CONTACT WITH THE BOX. LOCK THE SIDE RAILS BY TURNING THE HAND WHEEL CLOCKWISE. RELEASE THE HEAD BY TURNING THE HEAD LOCK HAND WHEEL COUNTERCLOCKWISE. LOWER THE HEAD UNTIL IT MAKES CONTACT WITH THE BOX; THEN PUT A SLIGHT ADDITIONAL PRESSURE ON THE BOX. LOCK THE HEAD LOCK HAND WHEEL CLOCKWISE.

START THE MACHINE WITH START SWITCH LOCATED ON THE OPERATOR SIDE OF THE MACHINE. SAMPLE BOX WILL BE TAPED AND DISCHARGED. MACHINE IS NOW READY TO PROCESS BOXES.

THE OPERATOR SHOULD FOLD THE BOX FLAPS IN THE NORMAL MANNER. WHILE HOLDING THE FLAPS CLOSED ON THE REAR OF THE BOX, THE OPERATOR SHOULD FEED THE BOX INTO THE MACHINE UNTIL THE BELTS TAKE IT. THE MACHINE WILL SEAL THE TOP AND BOTTOM FLAPS AND DISCHARGE THE BOX TO THE OUTFEED CONVEYOR AUTOMATICALLY.

Machine Maintenance:

Daily------ Clean machine (as required)
Inspect bottom belt drives.
Weekly----- Check belt tensioner
Inspect area around motor & gearbox
Inspect belt idlers
Adjust finger guards for belts (as required)
Inspect / Lubricate drive chain
Inspect / lubricate drive roller bearings
Monthly---- Check / Adjust head wear pads
Check drive roller belt lagging.

Cartridge Maintenance: Refer to cartridge area of manual

MAIN FRAME

STARTER SWITCH:

THE STARTER SWITCH IS MOUNTED ON THE OPERATOR SIDE OF THE MACHINE. TO REPLACE THIS SWITCH, FIRST DISCONNECT THE MACHINE FOR THE ELECTRICAL SUPPLY. REMOVE THE SWITCH BY LOOSENING THE TWO FASTENING SCREW AND PULL SWITCH FOR THE ELECTRICAL BOX. REMOVE THE SIRES AFTER FIRST NOTING THEIR CONNECTION TO THE SWITCH.

TO REPLACE THE STARTER SWITCH, REVERSE THE ABOVE PROCEDURE.

SIDE RAILS:

THE SIDE RAILS CENTER AND ALIGN THE BOX AS IT IS BEING PROCESSED. THEY ARE MANUALLY SET BY LOOSENING THE SIDE RAIL LOCK HAND WHEEL COUNTERCLOCKWISE. MOVE THE SIDE RAILS IN UNTIL BOTH SIDE RAILS COME IN CONTACT WITH THE BOX. RE-LOCK THE SIDE RAILS BY TURNING THE SIDE RAIL LOCK HAND WHEEL CLOCKWISE.

BELT THREADING DIAGRAM

KEY	PART NUMBER	DESCRIPTION
1	LDU-1128A-4	BELT
2	LDU-1064-5	DRIVE ROLLER
3	SPR-1016	BELT TENSIONING SPRING
4	K286	GUIDE ROLLER
5	LDU-1335-5	CONV. ROLLER BRACKET
6	PSC196-4	ROLLER

HEAD

THE HEAD TROLLEY ASSEMBLY TRAVELS ALONG THE MAST ON CAM BEARINGS AND UHMW WEAR PADS. THE HEIGHT OF THE HEAD IS ADJUSTED BY TURNING THE LOCK HAND KNOB COUNTERCLOCKWISE TO RELEASE THE HEAD. TURNING THE HAND WHEEL CLOCKWISE WILL LOCK THE HEAD IN THE DESIRED POSITION.

ADJUSTMENT OF HEAD ASSEMBLY

HEAD TROLLEY WEAR PAD ADJUSTMENT

SEE ASSEMBLY FOR INDIVIDUAL PART NUMBERS. THE ADJUSTMENT OF THE TROLLEY ASSEMBLY IS AS FOLLOWS.

- 1. DISCONNECT POWER FROM MACHINE AND LOCK OUT POWER USING LOCKOUT BRACKET ON STARTER SWITCH.
- 2. THERE ARE (4) NYLON PATCHED SET SCREWS LOCATED ON THE LOCK SIDE OF THE TROLLEY BLOCK. BY ADJUSTING THESE SET SCREWS INWARD THEY WILL REDUCE THE CLEARANCE BETWEEN THE WEAR PAD AND THE MAST. ADJUSTMENT OF THE PAD MUST BE UNIFORM ON ALL (4) SCREWS TO INSURE THAT PAD IS PARALLEL TO THE MAST. THE RECOMMENDED CLEARANCE IS APPROXIMATELY .020" OR .5 mm.
- 3. DURING THE ADJUSTMENT PROCESS SLIDE THE HEAD UP AND DOWN TO INSURE A SMOOTH MOVEMENT.

HEAD TROLLEY CAM BEARING ADJUSTMENT

THERE ARE (2) SETS OF CAM BEARINGS LOCATED IN THE TROLLEY ASSEMBLY. THE FIRST SET IS LOCATED IN THE FRONT OF THE HEAD LIFTING TROLLEY ASSEMBLY AND IS FIXED. THE SECOND SET IS LOCATED AT THE REAR OF THE ASSEMBLY AND IS MOVABLE. THE ADJUSTMENT OF THE REAR CAM BEARING ASSEMBLY IS AS FOLLOWS.

- 1. DISCONNECT POWER FROM MACHINE AND LOCK OUT POWER USING LOCKOUT BRACKET ON STARTER SWITCH.
- 2. REMOVE FRONT SPRING GUARD BY REMOVING THE (2) MOUNTING SCREWS LOCATED AT THE TOP OF THE GUARD.
- 3. THEN REMOVE THE MAST GUARD BY REMOVING ITS (8) MOUNTING SCREWS. THERE ARE (4) SCREWS LOCATED ON EACH SIDE OF THE GUARD JUST ABOVE AND BELOW THE SIDE CUT OUT. WITH THESE REMOVED THE GUARD WILL LIFT OFF.
- 4. ON THE TROLLEY ASSEMBLY THERE ARE (4) SET SCREWS. EACH SET SCREW PUSHES ON A TEE NUT THAT HOUSES THE CAM BAR SUPPORT. BY TURNING THE SET SCREW IN, THIS WILL DECREASE THE DISTANCE BETWEEN THE CAM BEARING AND THE MAST.
- 5. DURING THE ADJUSTMENT PROCESS SLIDE THE HEAD UP AND DOWN TO INSURE A SMOOTH MOVEMENT.

ELECTRICAL SYSTEM

THE ELECTRICAL SYSTEM CONSISTS OF THE DRIVE MOTOR WHICH INCORPORATES A FRACTIONAL HP A.C. MOTOR AND THE STARTER SWITCH. THE MOTOR AND FRAME ARE GROUNDED THROUGH THE STARTER SWITCH. THE STARTER SWITCH IS FASTENED TO THE MACHINE' S FRAME.

THE MOTOR STARTERS OVERLOAD RELAY IS FACTORY SET. IF IT TRIPS, A QUALIFIED ELECTRICIAN SHOULD CHECK THE ELECTRICAL SYSTEM, THEN RESET THE OVERLOAD RELAY.

THE BELTS ARE DRIVEN BY THE DRIVE MOTOR ON THE DISCHARGE END OF THE MACHINE. THE MOTOR IS CONTROLLED BY THE STARTER SWITCH IN WHICH THE HEATER IS FACTORY SET TO THE PROPER TRIP SETTING TO PROTECT THE MOTOR.

IF TROUBLE IS BEING EXPERIENCED WITH THE DRIVE MOTOR, A QUALIFIED ELECTRICIAN SHOULD FIRST CHECK THE STARTER SWITCH, THEN THE ELECTRICAL SYSTEM.

TO REPLACE THE DRIVE MOTOR, PROCEED AS FOLLOWS:

- DISCONNECT THE ELECTRICAL CONNECTIONS.
- REMOVE MOTOR FROM GEAR REDUCER, REPLACE MOTOR.
- TO CONNECT MOTOR, REFER TO WIRING DIAGRAM IN MOTOR JUNCTION BOX.
- CHECK MOTOR FOR PROPER ROTATION.

LUBRICATION

TAPE CARTRIDGE: ALL MECHANICAL PARTS ON THE LITTLE DAVID ARE PERMANENTLY LUBRICATED AND SEALED BEARINGS ARE USED THROUGHOUT.

MACHINE DRIVE SYSTEM:

IN ORDER TO GET THE MAXIMUM LIFE, COMPONENTS SHOULD HAVE CONSTANT LUBRICATION

SPROCKETS & CHAIN: PERIODIC LUBRICATION USING HIGH QUALITY CHAIN LUBE IS REQUIRED

DRIVE SHAFT BEARING: GREASE BEARINGS AT SAME INTERVAL AS SPROCKET & CHAIN

THE REDUCER HAS BEEN PRE-CHARGED AT THE FACTORY WITH SYNTHETIC LUBRICANT.

THE MAST SHOULD BE CLEANED AND SPRAYED WITH A SILICONE LUBRICANT - THIS SHOULD BE DONE ON A WEEKLY BASIS TO ENSURE FREE MOVEMENT OF THE HEAD.

TROUBLE SHOOTING

TAPING DIFFICULTIES:

PROBLEM:

1. TAPE DOES NOT ADHERE WELL TO BOX:

2. TAPE END STICKS TO ITSELF OR MECHANISM:

3. TAPE BREAKS OR JAMS:

SOLUTION:

- A. CHECK THAT BOX IS NOT WAXY OR OILY.
- B. CHECK THAT BOX IS PROPERLY CUT AND SCORED SO THAT THE FLAPS DO NOT OVERLAP. IF THE TAPE ADHERES TO THE TOP AND BOTTOM BUT NOT TO THE END PANELS, THE BOX MAY BE SKEWED FORMING A PARALLELOGRAM. IF THIS CONDITION EXISTS, BRING IT TO THE ATTENTION OF YOUR BOX SUPPLIER.
- C. CHECK THE PRESSURE ON THE WIPE DOWN ROLLERS. IF NECESSARY, INCREASE MAIN SPRING PRESSURE.
- D. CHECK THAT THE SPRING IS NOT BROKEN.
- A. CHECK THAT THERE IS NO TOO MUCH DRAG ON THE TAPE CAUSING STRETCHING AND SNAP BACK AT CUT OFF. REDUCE THE TAPE CORE DRAG SETTING.
- B. CHECK THE TAPE THREADING PATH.
- C. CHECK FOR DEFECTIVE TAPE ROLL BY PULLING TAPE OFF MANUALLY. THE PULL SHOULD BE EVEN AND NOT VARY SUDDENLY.
- D. CHECK TAPE GUIDE PLATE SETTING AND FREEDOM OF MOVEMENT.
- E. CHECK FOR BINDING.
- A. CHECK THE TAPE ROLL BY PULLING TAPE OFF MANUALLY. THE PULL SHOULD BE EVEN AND SHOULD NOT VARY SUDDENLY.
- B. CHECK THE TAPE CORE DRAG SETTING.
- C. CHECK THE TAPE THREADING PATH.
- D. CHECK FOR NICKS IN EDGE OF TAPE ROLL. PULL OFF DAMAGED TAPE.
- E. TAPE TENSION SET TOO HIGH.

LOVESHAW

4.	TAPE WRINKLES:	A.	CHECK THE TAPE ROLL BY PULLING TAPE OFF MANUALLY. THE PULL SHOULD BE EVEN AND SHOULD NOT VARY SUDDENLY.
		B.	CHECK THE PRESSURE OF THE WIPE DOWN ROLLERS. TOO MUCH OR NO PRESSURE MAY CAUSE WRINKLES. PRESSURE THAT IS TOO GREAT MAY DEPRESS THE FLAPS CAUSING PROBLEMS. IF NECESSARY, RE-ADJUST THE PRESSURE.
		C.	CHECK THAT ALL THE ROLLERS TURN FREELY ON THEIR SHAFTS.
		D.	CHECK THE BOX CONTENTS. PARTIALLY FULL BOXES OR VERY COMPRESSIBLE CONTENTS MAY ALLOW THE FLAPS TO EXCESSIVELY DEPRESS CAUSING WRINKLES.
		E.	CHECK THE DRAG OF THE TAPE. TOO MUCH DRAG MAY CAUSE OVERRUNNING OF THE TAPE ROLL. ADJUST THE TAPE CORE DRAG SETTING.
		F.	TAPE TENSION SET TOO HIGH.
		G.	CHECK ROLLER STOP INSIDE CARTRIDGE.
		H.	CHECK THAT TAPE IS PROPERLY THREADED AND THAT TAPE CORE IS PROPERLY CENTERED.
		I.	CHECK THE PRESSURE OF THE HEAD AGAINST THE BELTS AND HESITATE AS IT IS BEING FED THROUGH THE MACHINE. ADJUST THE HEIGHT.
		J.	CHECK THAT THE BELTS ARE NOT SLIPPING.
		K.	CHECK ADJUSTMENT OF THE GUIDE PLATE AND FINGER PLATE.
5.	SHORT TAPE TAB ON BOX:	A.	CHECK TAPE TENSION.
		B.	CHECK ROLLERS FOR BINDING.

6. TAPE NOT BEING WIPED ON BOTTOM OF BOX.

THERE ARE LARGE ECCENTRIC STOPS THAT ARE FACTORY SET TO INSURE THAT THE FRONT ROLLER ARM CANNOT BE DEPRESSED BELOW BOX HEIGHT. THEY ARE LOCATED INSIDE CARTRIDGE ON BOTH SIDES. WHEN FULLY DEPRESSED, THE FRONT WIPE ROLLER SHOULD PROTRUDE 3/32" ABOVE CARTRIDGE FRAME. IF THIS NEEDS ADJUSTING, ROTATE ECCENTRIC STOPS. USE BOTH STOPS AND MAKE SURE ROLLER ARM CONTACTS FLAT SURFACES. WHEN PROCESSING BOXES LESS THAN 5" HIGH, THE ECCENTRIC STOPS MUST BE MOVED TO THE HOLE IN THE CARTRIDGE FRAME. THE FRONT ROLLER SHOULD THEN PROTRUDE TO BELT LEVEL.

7.	TAPE NOT CUTTING:	Α.	CHECK KNIFE ARM FOR MECHANICAL BINDING.
		В.	CHECK THAT KNIFE IS NOT DULL.
		C.	CHECK SPRINGS ON KNIFE STUDS.
		D.	CHECK BUSHINGS IN KNIFE STUDS.
		E.	IF KNIFE STOP BLOCK IS CAUSING FRICTION ON KNIFE ARM STUDS, ROTATE UNTIL FREE.
		F.	TAPE TENSION IS SET TOO LOW.
8.	TAPE NOT CENTERED ON BOX:	A.	USE SCREW IN CENTER OF TAPE CORE TO RE-ALIGN.
9.	TAPE NOT BEING WIPED:	A.	CHECK MAIN SPRING.
		B.	TAPE TENSION IS SET TOO HIGH.
ΡΟΥ	PROBLEMS:		
		A.	STOP MACHINE.
1.	JAWI GLEAKING PROCEDURE.	A. B.	OPEN SIDE RAILS AND RAISE HEAD.
		C.	REMOVE JAMMED BOX. CUT TAPE FLUSH WITH END OF WIPE ROLLER.
		D.	RESET HEAD/SIDE RAILS TO A SAMPLE SIZE BOX.
		E.	START MACHINE. MACHINE IS NOW READY TO PROCESS THE NEXT BOX.
2.	INCORRECT BOX SIZE OR SHAPE:	A.	CHECK BOXES TO MAKE SURE THE SIZE FALLS WITHIN THE LIMITS OF THE MACHINE.
		В.	MACHINE WILL NOT PROCESS UNSTABLE BOXES.
3.	CONTENTS BULGING THROUGH TOP OF BOX:	A.	CHECK TO BE SURE BOX IS NOT OVERFILLED WITH CONTENTS.
4.	BOX SLIPPING AGAINST BELTS:	A.	INCREASE HEAD PRESSURE.
5.	SIDE RAIL PRESSURE TOO HIGH:	A.	OPEN SIDE RAILS SLIGHTLY.

LOVESHAW

6.	HEAD PRESSURE TOO HIGH:	А.	RAISE HEAD SLIGHTLY.
BELT	DRIVE PROBLEMS:		
CHEC	K THAT MACHINE IN CONNECTED TO A LIV	/E ELECTRIC	AL SOURCE.
1.	BELTS SLIP.	A.	RAISE HEAD SLIGHTLY.
		В.	REPLACE IS MISSING OR BROKEN.
2.	BOX SLIPS AGAINST BELTS:	A.	LOWER HEAD SLIGHTLY TO INCREASE PRESSURE ON BOX.
3.	BELTS RUB AGAINST FRAME:	A.	CHECK THAT BELTS ARE POSITIONED CORRECTLY IN BETWEEN THE BELT GUIDE ROLLERS.
		В.	CHECK FOR MISSING OR BROKEN BELT TENSIONING SPRINGS.

TAPE CARTRIDGE

TAPE TENSION ROLLER:

THE TAPE TENSION ROLLER MAINTAINS CONSTANT TENSION THROUGHOUT THE LIFE OF THE TAPE ROLL. IT HAS A ONE WAY CLUTCH TO PREVENT PULL BACK ON TAPE. TURNING THE NYLOK NUT CLOCKWISE INCREASES TENSION. COUNTERCLOCKWISE DECREASES TENSION. TOO MUCH TENSION WILL CAUSE PROBLEMS.

WIPE DOWN ROLLERS:

THE RUBBER WIPE DOWN ROLLERS WIPE THE TAPE ONTO THE BOX AS IT PASSES THROUGH THE MACHINE. THE FRONT ROLLER HAS A ONE WAY CLUTCH TO PREVENT KICKBACK OF TAPE. THE PRESSURE EXERTED BY THE ROLLERS IS ADJUSTABLE BY CHANGING THE POSITION OF THE MAIN SPRING TO A DIFFERENT HOLE ON THE MAIN TIE BAR. THE PRESSURE SHOULD BE SUFFICIENT TO OBTAIN A GOOD WIPE. TOO MUCH PRESSURE CAN CAUSE PREMATURE WEAR. PRESSURE SHOULD BE REDUCED FOR BOXES WITH UNDERFILL OR COMPRESSIBLE CONTENTS.

TAPE GUIDE PLATE:

THE TAPE IS GUIDED TO THE FRONT ROLLER BY THE TAPE GUIDE PLATE. THE FLAT PORTION OF THIS PLATE MUST BE TANGENT TO THE RUBBER ROLLER FOR PROPER FUNCTION. THIS IS ADJUSTABLE BY ROTATING THE ECCENTRIC STOP IT BEARS AGAINST. THE TAPE GUIDE PLATE IN CONJUNCTION WITH THE FINGER PLATE FORM THE TAPE WHICH ALLOWS IT TO STAND UP. THE TAPE GUIDE PLATE MOVES AS THE BOX PASSES, TO FORM A CORNER. THIS ENSURES SMOOTH TIGHT TAPE APPLICABLE TO THE LEADING CORNER OF THE BOX.

FINGER PLATE:

THE FINGER PLATE PRESSES AGAINST THE ADHESIVE SIDE OF THE TAPE AND FORCES THE TAPE TO TAKE THE SHAPE OF THE TAPE GUIDE PLATE. IT IS IMPORTANT THAT THE FINGERS JUST MAKE CONTACT WITH THE TAPE GUIDE PLATE, WHEN THERE IS NO TAPE IN CARTRIDGE. IF ADJUSTMENTS ARE NECESSARY,, GENTLY BEND THE FINGERS NEAR THE TIPS. ONLY BEND A SMALL AMOUNT, THEN CHECK. FINGERS MUST CONTACT PLATE. WHEN THE TAPE GUIDE PLATE IS MOVED THE FINGERS SHOULD NOT FOLLOW. **NOTE:** FINGERS SHOULD BE ABLE TO MOVE 1/8" AWAY FROM PLATE.

KNIFE ARM:

THE KNIFE ARM IS MOUNTED AT AN ANGLE TO CUT THE TAPE LIKE A SCISSORS. A STUD IS LOCATED ON THE MOUNTING BLOCK TO PREVENT INCORRECT REPLACEMENT OF KNIFE. THE KNIFE SHOULD BE CLEANED PERIODICALLY USING A RAG AND CLEANING FLUID. DO NOT USE A WIRE BRUSH OR OTHER ABRASIVE DEVICES. THE KNIFE ARM SHOULD BE ADJUSTED SO THAT THE TIPS OF THE KNIFE ARE 2 ½" FROM THE CARTRIDGE FRAME. (SEE ASSEMBLY DRAWING). THIS CAN BE ADJUSTED BY LOOSENING THE SMALL NUT ON THE KNIFE ARM STUD AND ROTATING THE STUD UNTIL THE LARGE NUT CONTACTS THE BUMPER AT THE DESIRED SETTING. KNIFE ARM TENSION IS CONTROLLED BY THE COMPRESSION SPRING ON THE STUD. TIGHTEN THE NYLOK NUT FOR GREATER TENSION. ALWAYS POWER DOWN MACHINE FIRST.

LOADING TAPE: PROCEDURE (TOP AND BOTTOM)

TOP TAPE:

- 1. REMOVE EXPIRED TAPE ROLL BY SLIDING IT OFF TAPE CORE ON MILL STAND, PULLING IT TOWARD THE REAR OF THE CARTRIDGE.
- 2. LOAD NEW ROLL OF TAPE ON TAPE CORE.
- 3. WITH LEFT HAND, GRAB CARTRIDGE NEAR TAPE CORE AND ROTATE UP/BACK UNTIL CARTRIDGE RESTS AGAINST STOP.
- 4. FOLD TAPE ON ITSELF TO PREVENT ADHESIVE FROM GRABBING CARTRIDGE (ABOUT 1 FT. IN LENGTH).
- 5. THREAD AS PER DIAGRAM.
- 6. ROTATE REAR ROLLER ARM TO EXPOSE KNIFE.
- 7. PULL EXCESS TAPE ACROSS KNIFE TO CUT OFF FOLDED TAPE.
- 8. RELEASE REAR ROLLER ARM.
- 9. GRAB TAPE ROLL WITH LEFT HAND AND ROTATE CARTRIDGE UNTIL IT SETS ON TOP LOAD BRACKET IN HEAD FRAME.

BOTTOM TAPE:

- 1. GRAB REAR ROLLERS. GRAB FRONT SHAFT OF CARTRIDGE.
- 2. RAISE REAR OF CARTRIDGE AND MOVE CARTRIDGE UP AND OUT OF MACHINE.
- 3. THREADING IS THE SAME AS TOP CARTRIDGE.
- 4. GRABBING THE CARTRIDGE BY REAR ROLLER AND FRONT SHAFT, ANGLE FRONT OF CARTRIDGE ONTO MOUNTING BOLTS AND THEN LOWER REAR OF CARTRIDGE.

LOVESHAW

ILLUSTRATED ASSEMBLY DRAWINGS TABLE OF CONTENTS

BASE FRAME ASSEMBLY

DRIVE ASSEMBLY - STANDARD

BELT DRIVE ASSEMBLY

DRIVE/MOTOR ASSEMBLY

HEAD ASSEMBLY

SIDE RAIL ASSEMBLY

MAST AND TROLLEY ASSEMBLY

TROLLEY ASSEMBLY

INFEED TABLE ASSEMBLY

INFEED ROLLER BED TABLE ASSEMBLY

LITTLE DAVID CASE SEALER LIMITED WARRANTY

THE LOVESHAW CORPORATION (HEREAFTER "LOVESHAW"), WARRANTS ONLY THAT THE GOODS SOLD BY IT SHALL BE FREE FROM DEFECTS IN MATERIAL AND WORKMANSHIP, UNDER PROPER AND NORMAL USE AND MAINTENANCE FOLLOWS:

DRIVE MOTOR: 1 YEAR

AS

 GEAR
 REDUCER:
 2
 YEARS

 TAPE CARTRIDGE:
 3 YEARS
 (EXCEPT FOR MOVING PARTS WHICH ARE SUBJECT TO NORMAL WEAR, TEAR AND REPLACEMENT WHICH ARE WARRANTED ONLY TO BE FREE FROM DEFECTS IN MATERIAL AND WORKMANSHIP).

 ALL OTHER PARTS:
 1 YEAR
 (EXCEPT FOR MOVING PARTS WHICH ARE SUBJECT TO NORMAL WEAR, TEAR AND REPLACEMENT WHICH ARE SUBJECT TO NORMAL WEAR, TEAR AND REPLACEMENT WHICH ARE SUBJECT TO NORMAL WEAR, TEAR AND REPLACEMENT WHICH ARE SUBJECT TO NORMAL WEAR, TEAR AND REPLACEMENT WHICH ARE SUBJECT TO NORMAL WEAR, TEAR AND REPLACEMENT WHICH ARE WARRANTED ONLY TO BE FREE

THE WARRANTY PERIOD SHALL COMMENCE AS OF THE DATE OF DELIVERY TO THE PURCHASER. THE OBLIGATION OF LOVESHAW UNDER THIS WARRANTY IS STRICTLY LIMITED TO THE COST OF REPAIRING OR REPLACING, AS LOVESHAW MAY ELECT, ANY PART OR PARTS THAT PROVE IN LOVESHAW'S JUDGMENT TO HAVE BEEN DEFECTIVE IN MATERIAL OR WORKMANSHIP AT THE TIME THE GOODS WERE SHIPPED FROM LOVESHAW'S PLANT. ANY WARRANTY CLAIM NOT MADE N WRITING TO LOVESHAW AT ITS HOME OFFICE WITHIN THE APPLICABLE WARRANTY PERIOD AND WITHIN **TEN** DAYS OF FAILURE WILL NOT BE VALID. THIS IS THE SOLE AND EXCLUSIVE REMEDY AVAILABLE UNDER THIS WARRANTY. UNDER NO CIRCUMSTANCES WILL LOVESHAW BE LIABLE FOR INCIDENTS, SPECIAL OR CONSEQUENTIAL DAMAGES.

FROM DEFECTS IN MATERIAL AND WORKMANSHIP).

IF REQUESTED BY LOVESHAW, PURCHASER SHALL RETURN ANY DEFECTIVE PART OR PARTS TO LOVESHAW'S PLANT FREIGHT PREPAID. ALL WARRANTY PART REPLACEMENTS AND/OR REPAIRS MUST BE MADE BY LOVESHAW OR BY A LOVESHAW DEALER AUTHORIZED TO HANDLE THE GOODS COVERED BY THIS WARRANTY. ANY OUTSIDE WORK OR ALTERNATIONS DONE WITHOUT LOVESHAW'S PRIOR WRITTEN APPROVAL WILL RENDER THIS WARRANTY VOID. LOVESHAW WILL NOT ASSUME ANY EXPENSE OR LIABILITY FOR ANY REPAIRS MADE TO ITS GOODS OUTSIDE ITS WORK WITHOUT ITS PRIOR WRITTEN CONSENT. THIS WARRANTY SHALL NOT APPLY TO ANY ITEM WHICH HAS NOT BEEN USED, OPERATED, AND MAINTAINED IN ACCORDANCE WITH LOVESHAW'S RECOMMENDED PROCEDURES. LOVESHAW SHALL HAVE NO LIABILITY WHATSOEVER WHERE THE GOODS HAVE BEEN ALTERED, MISUSED, OR INVOLVED IN AN ACCIDENT.

NO PERSON IS AUTHORIZED TO MAKE ANY WARRANTY OR TO CREATE ANY LIABILITY BINDING UPON LOVESHAW WHICH IS NOT STATED IN THIS WARRANTY. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES OF ANY KIND, EXPRESSED OR IMPLIED, WHICH ARE HEREBY EXCLUDED. IN PARTICULAR, THE IMPLIED MERCHANTABLE WARRANTY AS WELL AS THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY EXCLUDED.

UNIT WEST ANDOVER.

T F LOVESHAW - EUROPE 9, BRUNEL GATE PORTWAY INDUSTRIAL ESTATE HAMPSHIRE SP10 3SL ENGLAND EL: (0264) 357511 AX: (0264) 355964

MACHINE OPTIONAL ASSEMBLIES

<u>OPTIONS</u>	ASSEMBLY NUMBER
CASTERS	.LDC302
PACK TABLE	.ITA/LDU
PACK TABLE (ROLLER)	.ITA/RB/LDU
PACK TABLE (15 STYLE)	.ITA/LDU/15
THREE FLAP FOLDER	.TFF/LDU
CARTRIDGE WIPE BRUSH	.CWB/LDU
TOP SQUEEZER	.TSA/LDU
HIGH MAST	.HMTA/LDU
LEG EXTENSIONS (TO 36")	LDU-1015A-4
CASTERS (HEAVY DUTY)	.HDC100B/LDU
JET PRINTER BRACKET	
MOTOR KITS	
NEMA 4	
NEMA 7	
NEMA 12	

LOVESHAW



Special Note: Follow lock out/tag out procedures and use proper PPE (personal protection equipment) Safety glasses & gloves.

Figure 1

Tools required Loctite 277 & Hammer Hex Tee handle M3,4 & 5 Ratchet & 13mm socket 13mm wrench Spring hook *

Figure 2 Raise head assembly to highest setting. Lock hand knob.







Figure 5

Loosen and remove spring holder. (full replacement) Spring only loosen flat head screws and then remove shaft and spring assembly. (heat required)

Figure 6 Replace with new spring holder and new constant force spring assembly.

Figure 3 Remove mast cover. Using Hex Tee wrench (4) screws at top (4) screws at bottom

Figure 4

Remove <u>only</u> one screw from spring on trolley. Using spring hook, hold spring securely as second screw is removed. Release spring pressure.





Figure 7 Clean and then Loctite all hardware with #277.

<u>Figure 8</u> Tighten all hardware.





Figure 9

Using spring hook insert in hole (LH) hole. Apply Loctite to screws. Using hex Tee handle hold screw in (RH) hole.

Figure 10

Pull down spring till it is in line with trolley mounting holes. Insert screw but do not tighten completely.





Figure 12 Replace cover and adjust machine as normal.





Figure 11 Apply light pressure to fully tightening screws.


flatten out spring before Repeat on other side.

> (*) Spring hook is for single use only. Can be purchased at www.juddracing.com part number SP001

	4	1	3	$\mathbf{\Phi}$	2		1 REVISION HISTORY		
В	3			2			REVDESCRIPTIONDATEARELEASED4/24/2006		В
					ITEM Q ⁻ 1 2		S List DESCRIPTION BASE FRAME ASSEMBLY MAST AND TROLLEY ASSEMBLY		
A				5	3 4 5 6 N/S N/S 2 0R 2 N/S 0F	I .HDA/LDU/2 I .BDA/LDU/EXT I .SRA/LDU/EXT18 I .LDU/DRIVE/STD I .ITA/RB/LDU/2/ED 2 .CAC50 2 .CAC51	HEAD ASSEMBLY BELT DRIVE ASSEMBLY SIDE RAIL ASSEMBLY DRIVE ASSEMBLY PACK TABLE ASSEMBLY CARTRIDGE ASSEMBLY 2" CARTRIDGE ASSEMBLY 3" INFEED TABLE ASSEMBLY TOP SQUEEZER ASSEMBLY		4
А			MA C.R ST. S	.S. STD	OU AS CONFIDENTIAL PRPRIETARY IATTER THEROF SHALL NOT BE	TOLERANCES UNLESS OTHERWISE NOTED: .X = ±.050 INCH .XX = ±.015 .XXX = ±.005 .X = ±1.0mm METRIC .XX = ±.3mm .XXX = ±.1mm		, N/A	A
	4	1	WIT		IT OF LOVESHAW-ITW AND WILL BE	FRACTIONS ⁺ 1/64	DRAWN AMYR APPROV		

	REVISION HISTORY								
REV	DESCRIPTION	DATE BY							
A	RELEASED	4/24/2006	AMYR						

S :	LOVESHAW RT. 296, SOUTH CANAAN, PA.									
1/2 [°]										
125	DWG NO .LDU/2 -ORLDU/3	SCALE N/A								
-	MATERIAL N/A	CHECKED								
4	DRAWN AMYR	APPROVED								
	1									



	1	
	REVISION HISTORY]
	REV DESCRIPTION DATE BY	
	A RELEASED 10/4/2004 AMYR B M.C.R. #07-001 1/26/2007 AMYR	
	B M.C.R. #07-001 1/20/2007 AWTR	
		D
	Dorto List	
	Parts List	
ER	DESCRIPTION	
	MAIN FRAME	
	LEG - FRAME	
	LEG - FRAME	
	LEG - FRAME	
	BRACE HORIZONTAL FRONT/REAR	С
	BRACE HORIZONTAL OPER./MAST	
	BRACE HORIZONTAL OPER./MAST	
	LEG EXTENSION	
	BASE STIFFENER	
	BRACKET - MAST/BASE	1
	FILL PLATE - FRONT	1
	ELECTRICAL BOX PLATE	
	LEG EXTENSION STOP	
	BELT RUBBING STRIP	4
	CARTRIDGE STAND OFF (*) FOR 2" ONLY)	
	FINGER GUARD	
	FINGER GUARD	
	STIFFENER GUARD	
	LEG RULE 22.25 TO 36	
	HEX HEAD M8 X 12	
	HEX HD M12x20	
	BRACKET - CONVEYOR	
	LOCK WASHER M8	в
	SPRING WASHER M10	
	HEX NUT M10	
	BUT HD M10x20	
	HEX HD M10 X 20	
	HEX NUT M6	
	HEX HD M8x35	
	LOCK WASHER M6	
	HEX NUT M6	
	FHSC M6x16	
	SHCS M10x30	
	FHSH M5x8	
	BHCS M8x16	
	SNAP BUSHING	
	BHCS M8 X 12	1
	LOCK WASHER M8	1
	HEX JAM NUT M8 X 1.25	
5	LOVESHAW	А
	RT. 296, SOUTH CANAAN, PA.	ļ
1/2	FRAME ASSEMBLY LDU 2" - OR - 3"	
-		
z T	DWG NO .FRM/LDU/2-3/EXT SCALE N/A	
•	MATERIAL N/A CHECKED	1
	DRAWN AMYR APPROVED	1
-	DRAWN ANTA AFFROVED	

	4		3		∇	2					1		
						^					REVISION H		
						\square					ESCRIPTION	DATE	BY
						0 0 0					RELEASED .C.R. #08-008	4/14/2004	AMYR AMYR
					$\mathbf{\hat{\mathbf{A}}}$	0					.0.11. #00-000	10/13/2000	
		(2	5	6	() ()				1	Parts Lis	st		
			\prec		lina)		ITEM	QTY	PART	NUMBER	DESC	RIPTION	
							1	1	LDU-112	26-5 E	RACKET, GEA	AR BOX MO	UNT
				or on		(7)	2	1	LDU-112	27-5 E	RACKET, GEA	AR BOX SLI	DE
			- Wa				3	1	LDU-10	51-5 E	RACE, BOTTO	OM MOTOR	
'			P		(11)		4	1	LDU-10	52-5 E	RACE, MOTO	R	
		\rightarrow			\bigcirc		5	1	LDU-106	64-5 F	ROLLER, DRIV	E	
	(25)						6	1	LDU-108	30-3 K	EY, DRIVE SH	IAFT HUB	
	\sim			\sim			7	2	LDU-106	62-4 E	RACKET, BEA	RING	
				(14)			8	1	SPK-00	50 S	PROCKET		
		\sim	and a	\bigcirc			9	1	SEE CH	ART S	PROCKET		
			ک (ک				10	1	LDU-11	16-4 0	GUARD, CHAIN	J	
			ລ໌ ເ		(18)		11	2	BRG-10	19A E	BEARING		
			Or O				12	2	BSG-10	41 F	LANE BEARIN	IG	
							14	2	LP09-05	6 E	BELT LAGGING	}	
		6) °	\leq		\sim	F	15	2	FLWMF		OCK WASHER		
					(17)	F	16	2	FBHMF		UTTON HEAD	SCREW M	5 X 10
	· () (9)		\rightarrow		\bigcirc		17	6	FFWMH		LAT WASHER		
				1		Ī	18	4	FHHMH		IEX HEAD SCI		LG.
							19	6	FLWMH	P L	OCK WASHEF	R M8	
				\bigcirc		-	21	2	FHHMH		IEX HEAD SCI		
			\sum	(4)		1	22	4	FHHSH		IH 5/16-18 x 1		
			(2)	\sim			23	4	FLWSEI		OCK WASHEF		
				Y		T	24	4	FHHMH		IEX HEAD M8		
	0						25	2	SP-12-F		OLLAR		
						-	26	2	FHFNM		IEX NUT, M8		
		(23)	//			-	Г	·		·			_
				(26)			Ļ	ASSY. N		SPROCKET	GEAR BOX		۱.
							L	.LDUC	110	SPK-0023	RED-1001	80	
			0					.LDUC	110A	SPK-0049	RED-1005	60	
			N	MAT'L	PART #	CAD FILE Idu drive std	TOLF	ERANCES I	JNLESS	IOVF	SHAW	Con	npany
			Ð	C.R.S.	STD	PLOT DATE 10/15/2008		HERWISE N			. 296, SOUTH CA		iipariy
	(22)			ST. ST.	N/A	DRAWN DATE 4/14/2004	INCH .XX	=±.050 <=±.015 AN	NGLES + 1/2		SSEMBL	ווחוע	
	\bigcirc	(19)		STAINLE	SS : NO FINISH	DO NOT SCALE PRINT	.XX	<x =1.005<="" td=""><td></td><td></td><td></td><td></td><td></td></x>					
				LOVESHAW-ITV	V AND IS TO BE TREATED B	REON IS THE EXCLUSIVE PROPERTY OF YOU AS CONFIDENTIAL PRPRIETARY	METRIC	.XX =±.3mm	MACH. 125 FINISH	DWG NO .LDU/	DRIVE/STD	SCALE N	N/A
				REPRODUCED	OTHER THAN FOR YOUR ON	T MATTER THEROF SHALL NOT BE VN USE OR TO BE DISCLOSED TO OTHER SENT OF LOVESHAW-ITW AND WILL BE	-	.XXX =1.1mm		MATERIAL N/A		CHECKED	
					LOVESHAW-ITW UPON REC		FR/	ACTIONS	<u>+</u> 1/64	DRAWN AMY	R	APPROVE	D
	4		3	-	4	2	-				1		


REVISION HISTORY							
REV	DESCRIPTION	DATE	BY				
А	RELEASED	4/14/2004	AMYR				
В	M.C.R. #08-008	10/15/2008	AMYR				

	4	3		↓		2				TORY DATE BY 5/6/2004 AMY 12/14/2004 AMY 2/24/2009 AMY	YR YR
В						00000					В
Ф			2	16 1 6		ITEM 1 2 3 4 5 6	QTY 2 1 2 2 2 4 4 4	PART NUMBE LDU-1335-5 LDU-1098-4 LDU-1099-4 PSC196-4 PSC301224 K286D	Parts List ER DESCRIPTION TENSION ROLLER BRAC BAR - BELT TENSIONER BRACKET - TENSIONER INFEED ROLLER - LARG BUSHING ROLLER	BAR	¢
A			4		-	7 8 9 10 11 12 13 14 15 16	4 2 4 4 4 4 2 4 2 2 2 2	SPR-1016FHHMH120P10PSR609FLWSDPFHFNSEPFLWMHPFHHMH020P10SPC-1001FHFNMHPLDU-1549-3	COMPRESSION SPRING HEX HD M8 x 120 ROLL PIN LOCK WASHER 1/4 HEX NUT 1/4-20 LOCK WASHER M8 HHCS M8x20 SPLIT COLLAR 5/8" HEX NUT, M8 BELT ROLLER		A
			MAT'L C.R.S. ST. ST.	PART # STD N/A	CAD FILE bda_ PLOT DATE 2/24/ DRAWN DATE 5/	2009	OTH	RANCES UNLESS ERWISE NOTED: ±.050 ±.015 ANGLES ± 1/2	LOVESHAW RT. 296, SOUTH CAN		
			THIS DRAV LOVESHA' INFORMA' REPRODU WITHOUT	NLESS : NO FINISH WING AND SUBJECT MATTER THER W-ITW AND IS TO BE TREATED BY TION. THIS DRAWING OR SUBJECT I CED OTHER THAN FOR YOUR OWN THE EXPRESSED WRITTEN CONSE D TO LOVESHAW-ITW UPON REQUE	DO NOT SCAL EON IS THE EXCLUSIVE P OU AS CONFIDENTIAL PR MATTER THEROF SHALL N USE OR TO BE DISCLOSE NT OF I OVESHAW-ITW AN	E PRINT	.XXX .X METRIC.X .X	ANGLES ± 1/2 =±.005 =±1.0mm X =±.3mm XX =±.1mm CTIONS ± 1/64		SCALE N/A CHECKED APPROVED	
Ĺ	4	3	1	4		2	<u>ı</u>		1		

I								
REVISION HISTORY								
DESCRIPTION	DATE	BY						
RELEASED	5/6/2004	AMYR						
M.C.R. #04-035	12/14/2004	AMYR						
ADDED ITEM #16	2/24/2009	AMYR						
	DESCRIPTION RELEASED M.C.R. #04-035	DESCRIPTION DATE RELEASED 5/6/2004 M.C.R. #04-035 12/14/2004						

	REVISION HIS DESCRIPTION RELEASED	STORY DATE 10/5/2004	BY AMYR
	DESCRIPTION	DATE	
	RELEASED	10/5/2004	AMYR
			E
Parts List	t		
ITEM QTY PART NUMBER	DESCRIPT		
	BASE FRAME AS	SSEMBLY	
	BELT		_
	REDUCER		-
	MOTOR ELECTRIC BOX F		-
	MOTOR STARTE		-
.LDUC110A SPK-0049 RED-1005 L	MOTOR LD16B-2003A LD16B-2003A LD16B-2003A/LES	FT./MIN 80 60 6 8 80	
	ESHAW RT. 296, SOUTH CAN		
ST. ST. N/A DRAWN DATE 10/5/2004 X = ±.050 INCH XX = ±.015 ANGLES ± 1/2 DRIVE MC	IOTOR ASSEMBL		
I OVESHAWJITW AND IS TO BE TREATED BY YOU AS CONFIDENTIAL PROPRIETARY	IVE MOTOR ASSEMBLY	SCALE N	J/A
REPRODUCED OTHER THAN FOR YOUR OWN USE OR TO BE DISCLOSED TO OTHER IN A LETVICE IN/A	J/A	CHECKED	
4 3 4 2 FRACTIONS ± 1/64 DRAWN AM	MR	APPROVE	D

Parts List						
ITEM	QTY	PART NUMBER	DESCRIPTION			
1	1	LDU-1157-5	HEAD NECK			
2	1	LDU-1047-4	STIFFENER - HEAD NECK			
3	1	LDU-1067-4	HEAD GUARD - FRONT			
4	1	LDU-1151-5	HEAD GUARD - REAR			
5	1	LDU-1152-4	TOP LOAD BRACKET			
6	1	LDU-1153-3	SHAFT - CARTRIDGE STOP			
7	1	LDU-1161L-4	WEAR STRIP LEFT			
8	1	LDU-1161R-4	WEAR STRIP RIGHT			
9	2	LDU-1284-4	SPACER - HEAD L/R			
10	3	FFHMI020P88	FL. HD. SOC. CAP SCREW M10 X 20			
11	3	FLWMIP	LOCK WASHER M10			
12	3	FHFNMIP	HEX NUT M10			
13	3	FFHMF012P10	FL. HD. SOC. CAP SCREW M5 X 12			
14	6	FFWMFP	FLAT WASHER M5			
15	6	FFWMFP	FLAT WASHER M5			
16	3	FHDNMFP	HEX DOME NUT M5			
17	3	FHHMF012P10	HEX HEAD SCREW M5 X 12			
18	6	FHHMG016P10	HEX HEAD SCREW M6 X 16			
19	3	FHFNMGP	HEX HEAD NUT M6			
20	6	FFWMGP	WASHER M6			
21	6	FLWMGP	LOCK WASHER M6			
22	26	FLWMFP	LOCK WASHER M5			
23	12	FHDNMFP	HEX DOME NUT M5			
24	32	FFHF012P10	FLAT HEAD M5 X 12 LG.			
25	2	FSHMG025P10	SOC. HD. CAP SCREW M6 X 25			
26	6	FLWMGP	LOCK WASHER M6			
27	6	FHDNMGP	HEX DOME NUT M6			
28	14	FHFNMFP	HEX FLAT NUT M5			
29	4	FFHMG025P10	FLAT HEAD SCREW M6 X 25			
30	1	LDU-1155-6	PLATE, HEAD LH			
31	1	LDU-1154-6	PLATE, HEAD RH			
32	1	LDU-1055-5	BRACE, HEAD NECK			



 $\mathbf{\Phi}$

2

3

3

MAT'L	PART #	CAD FILE HDA LDU 2	TOLERANCES UNLESS	LOVESHAW		
C.R.S.	STD	PLOT DATE 1/5/2005	OTHERWISE NOTED:	RT. 296, SOUTH CANA	AN, PA.	
ST. ST.	N/A	DRAWN DATE 10/25/2004	.X =±.050 INCH .XX =±.015 ANGLES ±1/2			
STA	AINLESS : NO FINISH	DO NOT SCALE PRINT	.XXX ===.005	HEAD ASSEMBLY		
		G AND SUBJECT MATTER THEREON IS THE EXCLUSIVE PROPERTY OF W AND IS TO BE TREATED BY YOU AS CONFIDENTIAL PRPRIETARY METRIC XX = 1.3mm FINISH		DWG NO .HDA/LDU/2	SCALE N/A	
REPROD		USE OR TO BE DISCLOSED TO OTHER	.XXX =±.1mm	MATERIAL N/A	CHECKED	
	WITHOUT THE EXPRESSED WRITTEN CONSENT OF LOVESHAW-ITW AND WILL BE RETURNED TO LOVESHAW-ITW UPON REQUEST.		FRACTIONS ⁺ 1/64	DRAWN AMYR	APPROVED	
	<u>—</u>	2		1		

В

₽


А

4

4

1								
REVISION HISTORY								
REV	DESCRIPTION	DATE	BY					
А	RELEASED	1/5/2005	AMYR					

ITEM	QTY	PART NUMBER	DESCRIPTION		
1	1	LDU-1104-5	SIDE RAIL (RH) SIDE		
2	1	LDU-1203-5	SIDE RAIL (LH) SIDE PNEU.		
3	2	LDU-1032-4	SIDE RAIL BRACKET REAR		
4	1	LDU-1043-4	LOCK ROD		
5	1	LDU-1084-5	SIDE RAIL BRACKET (PNEU)		
6	4	BRG-1012	BEARING		
7	1	LDU-1167LE-5	SIDE RAIL TUBE EXT (18") LH		
8	1	LDU-1167RE-5	SIDE RAIL TUBE EXT (18") RH		
9	4	PSC511A	SIDE RAIL CAP		
10	1	LDU-1031L-4	SIDE RAIL BRACKET FRONT		
11	4	LDU-1107-3	SIDE RAIL SUPPORT STUD		
12	10	FLWMGP	LOCK WASHER M6		
13	10	FHFNMGP	HEX NUT M6		
14	1	LDU-1042-4	LOCK BLOCK		
15	2	FLWMFP	LOCK WASHER M5		
16	2	FHHMF025P10	HEX HD M5x25		
17	1	PSU166-4	SIDE RAIL HAND KNOB		
18	1	LDU-1240-4	LINK BAR - SIDE RAILS RANDOM		
19	2	PSC552	SPHERICAL ALIGN BEARING		
20	1	LDU-1059L-4	SIDE RAIL BRACE LEFT		
21	1	LDU-1059R-4	SIDE RAIL BRACE RIGHT		
22	4	FFHMG016P10	FHSC M6x16		
23	4	FLWMHP	LOCK WASHER M8		
24	4	FHFNMHP	HEX NUT M8		
25	4	FHHMH020P10	HEX HD M8x20		
26	4	FSHMH016P10	SHCS M8x16		
27	3	FFWSEP	FW 5/16		
28	1	FHHSH225P08	HEX HEAD 5/16-18 X 2 1/4 LG.		
29	2	FHJNSIP	HJN 5/16-24		
30	1	FHJNMIP	M10 HJN		
31	1	FNLNSHP	5/16 Std NC Nylock Nut		
32	1	FNLNSEP	1/4 Std NC Nylock Nut		
33	1	LDU-1258-4	SIDE RAIL BRACE		
34	2	FHHMG016P10	HEX HEAD SCREW M6 X 16		




	Φ	2		1		
				REVISION	HISTORY]
				REV DESCRIPTION	DATE BY	
				A RELEASED	10/4/2004 AMYR	_
6			(24)			в
MAT'L	PART #	CAD FILE sra_ldu_ext18		LOVESHAW		A
C.R.S.	STD	PLOT DATE 10/4/2004	OTHERWISE NOTED:	RT. 296, SOUTH CA	NAAN, PA.	
ST. ST.	N/A	DRAWN DATE 10/4/2004	.X = ±.050	TITLE		1
	INLESS : NO FINISH	DO NOT SCALE PRINT	INCH .XX = ±.015 ANGLES ± 1/2 .XXX = ±.005	SIDE RAIL ASSEN	/IBLY	
THIS DRA	WING AND SUBJECT MATTER THER		.X =±1.0mm METRIC .XX =±.3mm FINISH	DWG NO .SRA/LDU/EXT18	SCALE N/A	1
INFORMA REPROD	TION. THIS DRAWING OR SUBJECT I UCED OTHER THAN FOR YOUR OWN	MATTER THEROF SHALL NOT BE	.XXX =t.1mm	MATERIAL N/A	CHECKED	1
WITHOUT	THE EXPRESSED WRITTEN CONSE ED TO LOVESHAW-ITW UPON REQUE	NT OF LOVESHAW-ITW AND WILL BE	FRACTIONS ± 1/64	DRAWN AMYR	APPROVED	1
	Λ	2		1		J
	T	-		•		

В

₽

А

			I							
	4	3	-	2		<u> </u>		1		
		\frown				_		REVISION HIST		
		(8)				-				BY
						L	A	RELEASED 4/	18/2006 A	AMYR
	G									
										
	\prec						Parts Li			
	(11)				EM QTY	PART NUM		DESCRI	PTION	
						LDU-1135-5		PRING HOLDER		
	(10)					TROLLEY ASS	SY. S	EE NEXT PAGE		
в	\bigcirc				3 1	LDU-1130-6	M	IAST		в
В		\sim		4	4 1	LDU-1132-4	M	IAST SPACER		D
	(•			Į	5 1	LDU-1133-3	S	PRING SHAFT		
			6	(6 1	LDU-1143-4	S	PRING GUARD		
	(16)-				7 1	LDU-1144-5	M	IAST GUARD		
				8		LDU-1145-4		IAST CAP		
						LDU-1026-4		ONSTANT FORCE	SPRING	
	(15)					LDU-1027-4		PRING HUB		
	\lor \sim					LDU-1134-3		PRING SHAFT SPA	CER	
	(13					LDU-1323LA-4		TOP BUMPER HOL		
	•					LDU-1322-3		TOP BUMPER		
		(20)				LDU-1323RA-4		TOP BUMPER HOL		<u>т</u>
\rightarrow	• • (21					FHHMH070P1		IEX HD. M8 X 70mm	1LG.	
						FFWMHP		LAT WASHER M8		
						FLWMHP		OCK WASHER M8	_	
						FFHMH016P10		L. HEAD M8 X 16 L		
				2	20 4	FFHMG025P1	0 FI	LAT HEAD SCREW	M6 X 25	
				2	21 4	FBHMG010P1	0 B	UTT. HD. CAP SCE	RW M6 X 1	0 LG.
				2	22 4	FLWMGP	L	OCK WASHER M6		
				2	23 9	FBHMF010P10	о в	UTT. HD. SCREW I	M5 X 10	
			(27)	2	24 10	FLWMFP	L	OCK WASHER M5		
				2	25 4	FHHMJ050P88	3 H	IEX HEAD M12 X 5	0 LG.	
				2	26 4	FLWMJP	L	OCK WASHER M12	2	
	(25)	0	(26)	2	27 4	FHFNMJP	Н	IEX NUT M12		
				2	28 1	FSHMF012P10	0 S	OC. HD. CAP SCR	EW M5 X 12	2 LG.
А			4							A
		BERE I								
		OC	MAT'L PART #	CAD FILE mta_ldu_d			ΙΟ			———————————————————————————————————————
	(24))			TOLERANCE OTHERWIS			ESHAW		
		\frown	C.R.S. STD	PLOT DATE 4/18/2006	.X =±.050			RT. 296, SOUTH CANA	an, pa.	
		(23)	ST. ST. N/A	DRAWN DATE 11/6/2004	INCH .XX = +.015	ANGLES ⁺ 1/2 [°]		ND TROLLEY AS	SEMBI Y	
		\smile	STAINLESS : NO FINISH	DO NOT SCALE PRINT	.XXX = ±.005					
			THIS DRAWING AND SUBJECT MATTER THER LOVESHAW-ITW AND IS TO BE TREATED BY	EON IS THE EXCLUSIVE PROPERTY OF	.X =±1.0m METRIC .XX =±.3m	^m MACH. 125 DW0 ^m FINISH ₩ DW0	G NO .MT	ſA/LDU/D	SCALE N/A	<u>، ا</u>
)		INFORMATION. THIS DRAWING OR SUBJECT REPRODUCED OTHER THAN FOR YOUR OWN	MATTER THEROF SHALL NOT BE USE OR TO BE DISCLOSED TO OTHER	.XXX =±.1	mm	terial N/	/A	CHECKED	
			WITHOUT THE EXPRESSED WRITTEN CONSE RETURNED TO LOVESHAW-ITW UPON REQUI	NT OF LOVESHAW-ITW AND WILL BE	FRACTION			/YR	APPROVED	———————————————————————————————————————
	4	3	<u>4</u>	2	1		,,	1	1	
	•		T	L		•		·		



D

С

в

А

			2	1	_
				REVISION HISTORY REV DESCRIPTION DATE BY	_
				A RELEASED 4/18/2006 AMYR	
-					
(20)					
\searrow					D
	\frown				
	(9)	(2')		
/	/~	X	9		
	/				
\sim	A				
	SU .				
a' l					
XII.					
×	_				
	A				-
	SV B		(16)		
/		/			
	•				
	SV B				
\sim	~				
		(20)	1		
	3	U			
	SK.				
XII.					С
		(21)			
$\langle \rangle$		21)			
\rightarrow	、				
(9))				
					\triangleleft
			Part	is List	
	ITEM	QTY	PART NUMBER	DESCRIPTION	
	1		LDU-1142-4	TROLLEY GUARD	
	2		LDU-1023-3		
	3		LDU-1025-3	STRIP, WEAR (FIXED SIDE)	в
	4 5		PSC301322 PSC301324-3	CLAMP SW. SCREW CLAMP NUT HEAD	Ľ
	6		LDU-1073-4	SPRING BLOCK	
	7		LDU-1276-5	TROLLEY PLATE (FIXED SIDE)	
	8		LDU-1275-5	PLATE, TROLLEY (LOCK SIDE)	
	9	4	LDU-1190-3	T-NUT	
	10 (*)		LDU-1261B-3	ROLLER, ST. STEEL	
	11		LDU-1191-3	SHAFT, SUPPORT	
	12		LDU-1191A-3		
	13 (*) 14		J206-PS PSC311013	BEARING THRUST BEARING	
	14		LDU-1139-4	TROLLEY PLATE FRONT	
	16		FFHMH020P10	FLAT HEAD CAP SCREW M8 X 20 LG.	\vdash
	17		FFHMG035P10	FHSC M6x35 LG.	
	18		FLWMGP	LOCK WASHER M6	
	19		FHDNMGP	HEX DOME NUT M6	
	20		FFHMG016P10	FLAT HD. CAP SCREW M6 X 16	
	21 22		FFHMF012P10 SPH-1146	FLAT HD. M5 X 12 LG.	
	22		SPH-1146 FSSMG016B10	SET SCREW 5/16-18 x 5/16LG. SET SCREW M6 X 16 LG.	
l	20	-		OLT CONLEW MOX TO LO.	
					1


				A		
PART #	CAD FILE trolley assy Idu_d	TOLERANCES UNLESS	LOVESHAW	P		
STD	PLOT DATE 4/18/2006	OTHERWISE NOTED:	RT. 296, SOUTH CANAAN, PA.			
N/A	DRAWN DATE 4/18/2006	X = ±.050 INCH XX = ±.015 ANGLES ± 1/2				
: NO FINISH	DO NOT SCALE PRINT	.XXX =±.005	IRULLET ASSEN			
	EON IS THE EXCLUSIVE PROPERTY OF YOU AS CONFIDENTIAL PRPRIETARY	X = 1.0mm MACH. 125	DWG NO trolley assy Idu/d	SCALE N/A		
ER THAN FOR YOUR OWN	MATTER THEROF SHALL NOT BE USE OR TO BE DISCLOSED TO OTHER NT OF LOVESHAW JTW AND WILL BE	.XXX =t.1mm	MATERIAL N/A	CHECKED		
ESHAW-ITW UPON REQUEST.		FRACTIONS ± 1/64	DRAWN AMYR	APPROVED		
I	2			1		

4	3	\mathbf{A}	2		1
B (4) (1) (1) (1) (1) (1) (1) (1) (1) (1) (1			ITE 1 2 3 4 5 6 7 8 9 10 11 11 11 11 11 11 11 11 11 11 11 11	1 1 1 1 2 2 2 2 2 3 8 5 4 6 4 5 4 5 4 5 4 5 4 5 4 5 4	PART NUMBE LDU-1011L-5 LDU-1011R-5 LDU-1012L-4 LDU-1012R-4 LDU-1012R-4 OPU501 SPH-1054 LD12B-1027A OPU301104-3 HC-1015 M8 X 45 M8 X 1.25 M5 M5 X 16 M5 X 16 M5 X 25
			DATE 8/7/2006	.X =±.050 NCH .XX =±.015	/ISE NOTED: ANGLES ⁺ 1/2 [•]
			NOT SCALE PRINT	.XXX =+.00	05
		THIS DRAWING AND SUBJECT MATTER THEREON IS 1 LOVESHAW-ITW AND IS TO BE TREATED BY YOU AS C INFORMATION. THIS DRAWING OR SUBJECT MATTER REPRODUCED OTHER THAN FOR YOUR OWN USE OF WITHOUT THE EXPRESSED WRITTEN CONSENT OF LO RETURNED TO LOVESHAW-ITW UPON REQUEST.	THE EXCLUSIVE PROPERTY OF CONFIDENTIAL PRPRIETARY THEROF SHALL NOT BE TO BE DISCLOSED TO OTHER DVESHAW-ITW AND WILL BE	.X =±1.0 METRIC .XX =±.3 .XXX =± FRACTIC	^{Jmm} MACH. 125 ^{3mm} FINISH ↓ 1.1mm CNS + 1/64
4	3	4	2		

-5 SQUEEZER BRACKET RIGHT 4 SQUEEZER WHEEL BRACKET LEFT -4 SQUEEZER WHEEL BRACKET RIGHT BUSHING HEX. SOC. HD. CAP SCREW			1		
A RELEASED 8/13/2003 AMYR B B B BER DESCRIPTION B 5 SQUEEZER BRACKET LEFT B -5 SQUEEZER BRACKET RIGHT B 4 SQUEEZER WHEEL BRACKET LEFT BUSHING -4 SQUEEZER WHEEL BRACKET RIGHT BUSHING HEX. SOC. HD. CAP SCREW A SQUEEZER WHEEL -4 SQUEEZER WHEEL HEX.SOC. HD. CAP SCREW 7A SPACER HEX.SOC. HD. CAP SCREW 7A SPACER HAND KNOB WASHER HEX.NUT HEX.SOC. HD. CAP SCREW HEX NUT SPRING WASHER<					
Parts List BER DESCRIPTION 5 SQUEEZER BRACKET LEFT -5 SQUEEZER BRACKET RIGHT 4 SQUEEZER WHEEL BRACKET LEFT -4 SQUEEZER WHEEL BRACKET RIGHT BUSHING HEX. SOC. HD. CAP SCREW 7A SQUEEZER WHEEL I-3 SPACER HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW					
Parts List IBER DESCRIPTION -5 SQUEEZER BRACKET LEFT -5 SQUEEZER BRACKET RIGHT 4 SQUEEZER WHEEL BRACKET LEFT -4 SQUEEZER WHEEL BRACKET RIGHT BUSHING HEX. SOC. HD. CAP SCREW 7A SQUEEZER WHEEL I-3 SPACER HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW COUNTERSUNK SCREW		A RELEASED	8/13/2003	AMYF	2
Parts List IBER DESCRIPTION -5 SQUEEZER BRACKET LEFT -5 SQUEEZER BRACKET RIGHT 4 SQUEEZER WHEEL BRACKET LEFT -4 SQUEEZER WHEEL BRACKET RIGHT BUSHING HEX. SOC. HD. CAP SCREW 7A SQUEEZER WHEEL I-3 SPACER HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW COUNTERSUNK SCREW					
Parts List IBER DESCRIPTION -5 SQUEEZER BRACKET LEFT -5 SQUEEZER BRACKET RIGHT 4 SQUEEZER WHEEL BRACKET LEFT -4 SQUEEZER WHEEL BRACKET RIGHT BUSHING HEX. SOC. HD. CAP SCREW 7A SQUEEZER WHEEL I-3 SPACER HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW					
Parts List IBER DESCRIPTION -5 SQUEEZER BRACKET LEFT -5 SQUEEZER BRACKET RIGHT 4 SQUEEZER WHEEL BRACKET LEFT -4 SQUEEZER WHEEL BRACKET RIGHT BUSHING HEX. SOC. HD. CAP SCREW 7A SQUEEZER WHEEL I-3 SPACER HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW					
Parts List IBER DESCRIPTION -5 SQUEEZER BRACKET LEFT -5 SQUEEZER BRACKET RIGHT 4 SQUEEZER WHEEL BRACKET LEFT -4 SQUEEZER WHEEL BRACKET RIGHT BUSHING HEX. SOC. HD. CAP SCREW 7A SQUEEZER WHEEL I-3 SPACER HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW					
Parts List IBER DESCRIPTION -5 SQUEEZER BRACKET LEFT -5 SQUEEZER BRACKET RIGHT 4 SQUEEZER WHEEL BRACKET LEFT -4 SQUEEZER WHEEL BRACKET RIGHT BUSHING HEX. SOC. HD. CAP SCREW 7A SQUEEZER WHEEL I-3 SPACER HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW					
IBER DESCRIPTION -5 SQUEEZER BRACKET LEFT -5 SQUEEZER WHEEL BRACKET LEFT -4 SQUEEZER WHEEL BRACKET RIGHT -4 SQUEEZER WHEEL BRACKET RIGHT BUSHING HEX. SOC. HD. CAP SCREW 7A SQUEEZER WHEEL I-3 SPACER HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW COUNTERSUNK SCREW					В
IBER DESCRIPTION -5 SQUEEZER BRACKET LEFT -5 SQUEEZER WHEEL BRACKET LEFT -4 SQUEEZER WHEEL BRACKET RIGHT -4 SQUEEZER WHEEL BRACKET RIGHT BUSHING HEX. SOC. HD. CAP SCREW 7A SQUEEZER WHEEL I-3 SPACER HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW COUNTERSUNK SCREW					
 SQUEEZER BRACKET LEFT SQUEEZER BRACKET RIGHT SQUEEZER WHEEL BRACKET LEFT SQUEEZER WHEEL BRACKET RIGHT BUSHING HEX. SOC. HD. CAP SCREW SQUEEZER WHEEL SPACER HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW 		Parts List			
 -5 SQUEEZER BRACKET RIGHT 4 SQUEEZER WHEEL BRACKET LEFT -4 SQUEEZER WHEEL BRACKET RIGHT BUSHING HEX. SOC. HD. CAP SCREW 7A SQUEEZER WHEEL I-3 SPACER HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW 	IBER	DESCRIP	TION		
 4 SQUEEZER WHEEL BRACKET LEFT 4 SQUEEZER WHEEL BRACKET RIGHT BUSHING HEX. SOC. HD. CAP SCREW 7A SQUEEZER WHEEL I-3 SPACER HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW 	-5	SQUEEZER BRACKET	LEFT		
 4 SQUEEZER WHEEL BRACKET LEFT 4 SQUEEZER WHEEL BRACKET RIGHT BUSHING HEX. SOC. HD. CAP SCREW 7A SQUEEZER WHEEL I-3 SPACER HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW 	-5	SQUEEZER BRACKET	RIGHT		
BUSHING HEX. SOC. HD. CAP SCREW A SQUEEZER WHEEL -3 SPACER HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW	4	SQUEEZER WHEEL BI	RACKET LEF	T	
HEX. SOC. HD. CAP SCREW A SQUEEZER WHEEL A SPACER HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW	-4	SQUEEZER WHEEL BI	RACKET RIG	iΗT	
7A SQUEEZER WHEEL I-3 SPACER HAND KNOB HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW SCREW		BUSHING			
I-3 SPACER HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW		HEX. SOC. HD. CAP S	CREW		
HAND KNOB WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW	7A	SQUEEZER WHEEL			
WASHER HEX HEAD BOLT NYLOCK HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW	-3	SPACER			k-
HEX HEAD BOLT NYLOCK HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW		HAND KNOB			
NYLOCK HEX NUT HEX NUT SPRING WASHER COUNTERSUNK SCREW		-			
HEX NUT SPRING WASHER COUNTERSUNK SCREW		HEX HEAD BOLT			
SPRING WASHER COUNTERSUNK SCREW					
COUNTERSUNK SCREW		_			
		COUNTERSUNK SCRE	EW		

S S	LOVESHAW	
	RT. 296, SOUTH CANA TITLE	AN, PA.
1/2 [°]	TOP SQUEEZER ASSEMBL	Y LDU
	DWG NO .TSA/LDU	SCALE N/A
125	DWGNO .TSALDO	SCALE N/A
	MATERIALOPTIONAL	CHECKED
4	DRAWN AMYR	APPROVED
	1	

А



		1	
	REVISION	HISTORY	
EV	DESCRIPTION	DATE	BY
A	RELEASED	3/15/2005	AJS

В

А

Parts List	
T NUMBER	DESCRIPTION
3-6	TABLE, PACK
4-4	COVER, PACK TABLE
	,

SS):	LOVESHAW RT. 296, SOUTH CANA	AN, PA.
1/2 [°]		SSY. LDU
125	DWG NO ITA LDU	SCALE N/A
	MATERIAL NOTED	CHECKED
4	DRAWN tonys	APPROVED
	1	

-	4	3	\mathbf{A}	2
В				
A				ITEM QTY PART NUM 1 1 LDU-1038C-6 2 1 LDU-1004A-4 3 4 FHHMI020P88 4 4 FLWMIP
A			C.R.S. STD PLOT DAT ST. ST. N/A DRAWN D	OF SHALL NOT BE XXX = 1 mm

4

3

2

4

	1		
	REVISION H	ISTORY	
REV	DESCRIPTION	DATE	BY
А	RELEASED	10/1/2004	AMYR


В

 \mathbf{A}

Α

Parts Lis	st
JMBER	DESCRIPTION
-6	PACK TABLE
-4	PACK TABLE COVER
P88	HEX HD SCREW M10 X 20
	SPRING WASHER M10

S UNLESS E NOTED:	LC	NESHAW RT. 296, SOUTH CA	NAAN, PA.
ANGLES + 1/2		EED TABLE A	SSEMBLY
ⁿ MACH. ₁₂₅ ^m FINISH ╹	DWG NO	.ITA/LDU/ED	SCALE N/A
nm	MATERIAL	N/A	CHECKED
NS ±1/64	DRAWN	AMYR	APPROVED
		1	





		1		_
EV	REVISION DESCRIPTION	I HISTORY	BY	-
EV A	RELEASED	3/15/2005	AJS	1
				D
	s List	00107161		1
BEF	TABLE, PACH			
	BRACKET, R		ORT	1
	ROLLER, PA			L
	SHAFT, ROLI			1
	ROLLER END			
	FLAT HD. M5 LOCK WASH			1
	HEX FLAT NU			
	HEX HD M10			
	SPRING WAS			1
				1
				с
				1
				4
	5			1
	γ			1
\searrow	\downarrow \checkmark (2		1
	@ 4_ /	\bigcirc		1
0	- Al			
	2			
2	/:			в
	7			1
5	\sim 1			1
-	7			
	8			1
	0			
				1
				1
				\vdash
				1
				1
				1
				1
				1
SS	LOVESI	HAW		A
D:		, SOUTH CANA	AN, PA.	
± 1/2	TITLE		DLLER) LDU	1
				4
125	DWG NO ITA RB LDU	J	SCALE N/A	4
4	MATERIAL NOTED		CHECKED	-
•	DAMIN CONJO	1	MINOVED	L
		-		


A RELEASED 32282005 АА 8 7 8 7 8 7 8 10 <td< th=""><th></th><th>4</th><th>3</th><th></th><th>$\mathbf{\Phi}$</th><th></th><th>2</th><th></th><th></th><th>1</th><th></th><th></th><th>_</th></td<>		4	3		$\mathbf{\Phi}$		2			1			_
		Ť								REV DESCRIPTIC	N DATE	BY	
B Parts List 7 B 9 B 10 DU-1035-6 11 DU-1035-6 12 DU-1035-6 13 DU-1035-6 14 DU-1035-6 15 DU-1035-6 14 DU-1035-6 15 DU-1035-6 16 DU-1035-6 16 DU-1035-6 17 DU-1035-6 18 FLWMEP 19 DU-1035-6 10 DU-1035-6 10 DU-1035-6 10 DU-1035-7 10 DU-1035-8			\frown							A RELEASED) 3/28/2005 /	<u>AMYR</u>	_
Image: constraint of the second state of the second sta													
Image: Construction of the second state priority of the second state prior to state													
Image: constraint of the second state of the second sta													
Image: constraint of the second state state of the second state s													
Image: Construction of the state of the	В		•										В
Image: Construction of the state of the			·										
A A A A A A A A A A A A A A													
A A A A A A A A A A A A A A													
A A A A A A A A A A A A A A													
A A A A A A A A A A A A A A									P	arts List			
A A A A A A A A A A A A A A							ITEM	QTY PART			N		
A A A A A A A A A A A A A A							I						
A A A A A A A A A A A A A A		i i											
Image: Status Barbon Scale Print Status Barbon Scale Print Content Scale Print <thconten< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>RT (DUAL)</td><td></td><td></td></thconten<>											RT (DUAL)		
A	Ð												\mathbf{A}
A A A A A A A A A A A A A A													
A 3 12 13 14 13 14 13 12 14 13 12 14 13 12 14 13 12 14 13 12 14 13 14 13 12 14 13 14 13 14 13 14 15 16 16 17 17 18 18 18 19 18 18 19 18 18 19 10 10 10 10 10 10 10 12 2 10 10 10 12 2 10 10 10 12 2 10 10 10 12 2 10 10 10 12 2 10 10 10 12 2 10 10 10 10 10 10 10 10 10 10													
A 9 8 FHFNMFP HEX FLAT NUT M5 10 8 FLWMFP LOCK WASHER M5 11 8 FFHMF012P10 FLAT HEAD BX 12 LG. 12 2 LDU-1007C-4 ROLLER, PACK TABLE 13 2 LDU-1354-3 ROLLER SPACER 14 1 LDU-1007D-4 ROLLER, PACK TABLE 14 1 LDU-1007D-4 ROLLER, PACK TABLE 15 STD FLOT DATE 3/28/2005 THERWISE NOTED: 8 STD FLOT DATE 3/28/2005 THERWISE NOTED: 8 STD FLOT DATE 3/28/2005 NTHERWISE NOTED: 8 S							8						
A A A A A A (13) (14) (14) (13) (14) (13) (14) (13) (14) (13) (14) (13) (14) (13) (12) (12) (12) (12) (12) (12) (12) (12) (12) (12) (12) (12) (12) (12) (12) (12) (12) (12) (12) (13) (12) (13) (12) (13) (12) (13) (12) (13) (12) (13) (13) (12) (13) (13) (12) (13) (12) (13) (12) (13) (12) (13) (12) (13) (12) (13) (12) (13) (12) (13) (12) (13) (12) (13) (12) (13) (12) (13) (12) (13) (12) (13) (12) (13) (12) (13) (13) (13) (13) (13) (13) (13) (14) (13) (14) (13) (14) (13) (14) (13) (14) (13) (14) (14) (15) (14) (14) (15) (14) (14) (15) (14) (14) (15) (14) (15) (14) (14) (15) (14) (14) (15) (14) (15) (14) (15)							9	8 FHFNM	FP	HEX FLAT NUT M5			
A A A A A A A A A A A A A A							10						
A A A A A A A A A A A A A A				5	\frown								
A 12 14 1 LDU-1007D-4 ROLLER, PACK TABLE 14 1 LDU-1007D-4 ROLLER, PACK TABLE 10 10 10 10 10 10 10 10 10 10			I ANNA INANA		(2)								
A (12) 10 10 10 10 10 10 10 1			INN INN I										
MAT'L PART # CAD FILE ita rb Idu ed TOLERANCES UNLESS OTHERWISE NOTED: LOVESHAW RT. 296, SOUTH CANAAN, PA. 9 ST. ST. N/A DRAWN DATE 3/28/2005 TOLERANCES UNLESS OTHERWISE NOTED: Ital 10 ST. ST. N/A DRAWN DATE 3/28/2005 TOLERANCES UNLESS OTHERWISE NOTED: Ital 10 ST. ST. N/A DRAWN DATE 3/28/2005 TILE Ital 10 STAINLESS : NO FINISH DO NOT SCALE PRINT INGLES ± 1/2 .XXX = ±.005 TITLE		(12)					14		070-4	KULLER, FAUR TADLE			
MAT'L PART # CAD FILE ita rb Idu ed TOLERANCES UNLESS OTHERWISE NOTED: LOVESHAW RT. 296, SOUTH CANAAN, PA. 9 ST. ST. N/A DRAWN DATE 3/28/2005 TOLERANCES UNLESS OTHERWISE NOTED: Ital 10 ST. ST. N/A DRAWN DATE 3/28/2005 TOLERANCES UNLESS OTHERWISE NOTED: Ital 10 ST. ST. N/A DRAWN DATE 3/28/2005 TILE Ital 10 STAINLESS : NO FINISH DO NOT SCALE PRINT INGLES ± 1/2 .XXX = ±.005 TITLE		\smile											
MAT'L PART # CAD FILE ita rb Idu ed TOLERANCES UNLESS OTHERWISE NOTED: LOVESHAW RT. 296, SOUTH CANAAN, PA. 9 ST. ST. N/A DRAWN DATE 3/28/2005 TOLERANCES UNLESS OTHERWISE NOTED: INCH. XX = ±.015 NCH. XX = ±.015 INTLE STAINLESS : NO FINISH DO NOT SCALE PRINT XXX = ±.015 XXX = ±.005 ANGLES ± 1/2 XXX = ±.005 INTLE	А			•									А
MAT'L PART # CAD FILE ita rb Idu ed TOLERANCES UNLESS OTHERWISE NOTED: LOVESHAW RT. 296, SOUTH CANAAN, PA. 9 ST. ST. N/A DRAWN DATE 3/28/2005 TOLERANCES UNLESS OTHERWISE NOTED: INCH. XX = ±.015 NCH. XX = ±.015 INTLE STAINLESS : NO FINISH DO NOT SCALE PRINT XXX = ±.015 XXX = ±.005 ANGLES ± 1/2 XXX = ±.005 INTLE													4
9 ST. ST. N/A DRAWN DATE 3/28/2005 STAINLESS: NO FINISH DO NOT SCALE PRINT STAINLESS: NO FINISH DO NOT SCALE PRINT													
STAINLESS : NO FINISH DO NOT SCALE PRINT XXX = 1.005											ANAAN, PA.		_
STAINLESS. NO FINISH DO NOT SOALL FRINT			9					INCH .XX = ±.015 .XXX = ±.005			ABLE ASSEME	3LY	
THIS DRAWING AND SUBJECT MATTER THEREON IS THE EXCLUSIVE PROPERTY OF MACH. 125 DWG NO .ITA/RB/LDU/ED SCALE N/A			+	THIS DRAWING AND SUBJE		N IS THE EXCLUSIVE PROPI	ERTY OF	.X =±1.0mm		WG NO .ITA/RB/LDU/ED	SCALE N/A		1
INFORMATION. THIS DAWING ON THE TREATED BY YOU AS CONFIDENTIAL PROFEITARY INFORMATION THIS ACCONFIDENTIAL PROFEITARY INFORMATION THE ACCONFIDENTIAL PROFEITARY				INFORMATION. THIS DRAW	ING OR SUBJECT MAT	TER THEROF SHALL NOT E	ETARY BE O OTHER	.XXX =±.1mm		IATERIAL N/A			1
REPRODUCED OTHER THAN FOR YOUR OWN USE OR TO BE DISCLOSED TO OTHER WITHOUT THE EXPRESSED WRITTEN CONSENT OF LOVESHAW-ITW AND WILL BE RETURNED TO LOVESHAW-ITW UPON REQUEST. MATERIAL N/A CHECKED MATERIAL N/A CHECKED CHECKED				WITHOUT THE EXPRESSED RETURNED TO LOVESHAW	O WRITTEN CONSENT	OF LOVESHAW-ITW AND W	ILL BE	FRACTIONS	± 1/64 📘	DRAWN AMYR	APPROVED		1
4 3 <u>4</u> 2 1	L	4	3		4		2	•	1	1	1		


				1						
	REVISION HISTORY									
		REV		RIPTIO		DATE		BY		
		A	REL	EASED		3/28/200	5	AMYR		
art	s Lis	st								
			DESC	RIPTIO	Ν					
	PAC	CK TAB	LE (RC	DLLER)	EX	T. DR				
	BR	T. RO	LLER S		RΤ	(DUAL)				
	BRł	KT. RO	LLER S	UPPOF	RΤ	(DUAL)				
	ROI	LLER, F	PACK T	ABLE						
	ROI	LLER E	ND PL	UG						
	SHA	AFT, RO	OLLER							
				R M10						
	нн	CS M10	X 20							
	1	<pre>/ /</pre>		-						


		_		1									
	4		3	∇		2				1	TOD /		٦
			\bigcirc					-		REVISION HIS			-
			(8)					-	REV	DESCRIPTION		BY	-
								L	A	RELEASED	11/06/04	AMYR	-
			(9)		Г				D (1.1.1			-
	\frown				-					s List			-
	(11		(5)		-	ITEM	QTY	PART NI			RIPTION		4
	\bigcirc				-	1		LDU-1135-5		SPRING HOLDER			_
		(10)	\sim		-	2	1	TROLLEY A	SSY.	SEE NEXT PAGE			_
в			(19)		_	3	1	LDU-1165-6	SS	HIGH MAST			B
						4	1	LDU-1132-4	ļ	MAST SPACER			
						5	1	LDU-1133-3	}	SPRING SHAFT			
	,			6		6	1	LDU-1143-4		SPRING GUARD			1
	(16				7	1	LDU-1166-5	5	MAST GUARD			1
	(14)				-	8		LDU-1145-4		MAST CAP			1
					-	9		LDU-1026-4		CONSTANT FOR			1
	(15)				-	10		LDU-1027-4		SPRING HUB			-
			\sim (12)		-	10		LDU-1134-3		SPRING SHAFT S			-
					-	12		LDU-1323L		STOP BUMPER H		т	-
	•				-			LDU-1323L/ LDU-1322-3					-
		(22)	(20)		-	13				STOP BUMPER			-
		Act I	\bigcirc		-	14		LDU-1323R		STOP BUMPER H		ΡΗΙ	-
Ð		(21)			-	15		FHHMH070	P10	HEX HD. M8 X 70			\mathbf{A}
	•		\bigcirc		-	16		FFWMHP		FLAT WASHER M			
			2		-	17		FLWMHP		LOCK WASHER M			_
					-	19	2	FFHMH016	P10	FL. HEAD M8 X 16	6 LG.		
			\bigcirc			20	4	FFHMG025	P10	FLAT HEAD SCRE	EW M6 X 25		
			(3)			21	4	FBHMG010	P10	BUTT. HD. CAP S	CERW M6 X	(10 LG.	
					-	22	4	FLWMGP		LOCK WASHER M	/16		1
		/ /				23	9	FBHMF010	P10	BUTT. HD. SCRE	N M5 X 10		1
				(27)		24	10	FLWMFP		LOCK WASHER M	15		1
					-	25	4	FHHMJ050	288	HEX HEAD M12 >	K 50 LG.		1
					-	26		FLWMJP		LOCK WASHER M			-
		25		(26)	-	27		FHFNMJP		HEX NUT M12	··-		-
				$\overline{}$	-	28		FSHMF012	D10	SOC. HD. CAP SC		1216	-
А			(4)	-	29		FHFNMHP	10	HEX NUT, M8		12 LO.	A
		OF OF O		\sim	L	29	2						-
		O OF			and the law d	omy		r	T O				-
		(24)		MAT'L PART #	CAD FILE hmta_ldu_d	10		S UNLESS	LO	VESHAW			
		\sim		C.R.S. STD	PLOT DATE 6/2/2008		THERWIS			RT. 296, SOUTH CA	Anaan, pa.		
		(23)		ST. ST. N/A	DRAWN DATE 11/6/20	04 INCH	.X =±.050 .XX =±.015	ANGLES + 1/2	TITLE			V	
	•	\sim		STAINLESS : NO FINISH	DO NOT SCALE PR		XXX ==005		IVIA91	AND TROLLEY /	HOOEIVIBL	I	
		/		THIS DRAWING AND SUBJECT MATTER TH			.X =±1.0mr	n MACH. 125 n FINISH	DWG NO	.HMTA/LDU/D-AMY	SCALE N	J/A	1
	\checkmark			LOVESHAW-ITW AND IS TO BE TREATED B INFORMATION. THIS DRAWING OR SUBJECT	Y YOU AS CONFIDENTIAL PRPRIETAR		.XXX = 1.3mr .XXX = 1.1n	hm	MATERIAL	N/A	CHECKED		1
				REPRODUCED OTHER THAN FOR YOUR O' WITHOUT THE EXPRESSED WRITTEN CON RETURNED TO LOVESHAW-ITW UPON REC	SENT OF LOVESHAW-ITW AND WILL E			IS ±1/64					-
			0					13 - 1/04	DRAWN	AMYR	APPROVE	U	
	4	I	3	4		2		I		1			









































TOLERANCES THE LOVESHAW CORPORATION AS NOTED RT 296, SOUTH CANAAN, PA. DECMAL TITLE: ELECTRICAL SCHEMATIC +/005 LD7 W/ SECONDARY STOP FRACTIONAL DWG. NO. ED779 SCALE: N/A +/ 1/2' DESIGNED: MENTA DRAWN: WM APRVD:	REVISION RECORD INCOMING POWER 1200/160 INCOMING POWER I200/160 I200/170 I200/16
---	--